AUTODOC CLUB

How to change air filter on **AUDI A3 Hatchback (8P1)** – replacement guide

SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

Important!

This replacement procedure can be used for:
AUDI A3 Hatchback (8P1) 1.6 E-Power, AUDI A3 Hatchback (8P1) 2.0 FSI, AUDI A3 Hatchback (8P1) 1.6, AUDI A3 Hatchback (8P1) 1.4 TFSI, AUDI A3 Hatchback (8P1) 1.2 TSI

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: AUDI A3 Sportback (8PA) 1.2 TSI

REPLACEMENT: AIR FILTER – AUDI A3 HATCHBACK (8P1). LIST OF THE TOOLS YOU'LL NEED:



- Phillips screwdriver
- Microfibre towel
- Fender cover

Buy tools

Replacement: air filter – AUDI A3 Hatchback (8P1). Tip from AUTODOC experts:

- Follow the terms, recommendations and requirements of the part operation provided by the manufacturer.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – AUDI A3 HATCHBACK (8P1). RECOMMENDED SEQUENCE OF STEPS:


1 Open the bonnet.

2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3 Undo the fastening screws of the air filter cover. Use a Phillips screwdriver.



4 Take off the filter lid.




5 Unscrew the air filter housing bracket. Use a Phillips screwdriver.



6 Remove the filter element from the filter housing.




7 Clean the air filter cover and housing.



Replacement: air filter – AUDI A3 Hatchback (8P1). Tip from AUTODOC:

- Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.


8 Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



Replacement: air filter – AUDI A3 Hatchback (8P1). Professionals recommend:

- Check out the correct location of the filter element. Do not skew.
- Attention! Use quality filters – AUDI A3 Hatchback (8P1).
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.

9 Screw in the air filter housing bracket. Use a Phillips screwdriver.



10 Reinstall the air filter cover. Fasten it.



11 Screw in the fastening screws of the air filter cover. Use a Phillips screwdriver.



12 Remove the fender protection cover.

13 Close the hood.

WELL DONE!

VIEW MORE TUTORIALS

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.